





INSTRUCTION MANUAL


INDOOR / OUTDOOR AMPLIFIED HDTV ANTENNA




BOX INCLUDES



Antenna




Coaxial Cable



Power Injector



Coaxial Adapter



USB Power Adapter*

*Actual USB power adapter may differ in appearance.

Antenna Mounting Hardware



x4 - Screws




x4 - Washers



x4 - Outdoor Screws



x2 - Wingnuts




x1 - U-Bolt




x2 - Carriage Bolts



x2 - Flange Nuts



Two and Four Hole
Antenna Mounting Brackets
with Teeth




Tube Mounting Bracket



Mounting Tube

Para español, visite gomohu.com/setup

RF SPLITTER (NOT PROVIDED) INSTALLATION





1

Select mounting location, ideally wood framework (in attic) or outside (roof / siding).

A Position the mounting bracket (flat surface to wood) to create an “I” shape when viewed from straight on.

B Secure the mounting bracket by using the four large outdoor screws.




2

Place the u-bolt under the bottom toothed plate, and secure the plate with the four included screws and washers to the antenna.


Sandwich the mounting tube between the bottom and top toothed brackets and secure with the included wingnuts.

Insert the short end of the mounting tube into the mounting bracket.

Use the two Carriage bolts and washers to secure the mounting tube to the mounting bracket.



3



The power injector must be connected in order for the antenna to function. Attach the antenna to the end of the power injector using the long coaxial cable. Plug the the injector's USB cable into the included AC power adaptor or other USB power source. Plug the coaxial adapter into the Power Bridge and attach the power injector's coaxial cable.